
IR Remote Controller DWSP-VACREMOTE



1. Power: System ON/OFF
2. NVR ID Selection
3. Numeric Button: Channel selection or Password input
4. PTZ Button
5. Preset Button: Select Preset in PTZ mode
6. Focus Button: Focus IN/OUT in PTZ mode
7. ZOOM Button: Zoom IN/OUT in PTZ mode
8. Preset Tour: Tour ON/OFF in PTZ mode
9. Direction Button
10. Enter Button
11. Menu Button
12. Return Button
13. Playback Buttons on Search mode
14. Emergency Recording Button
15. Auto-Sequence Button in Live mode
16. Screen Mode Button
17. Backup Button

Note Users can control multiple NVRs with one IR remote controller.
To control multiple NVRs, each NVR must have a different remote ID.
(The default remote ID is "0".)

To setup the ID # in the IR remote controller

- 1) Press and hold the ID selection button (②) for 5 seconds.
 - 2) Set the new ID by pressing the numeric button on the IR remote controller. The ID number range is from 000 up to 255.
 - 3) Press the numeric button in a three-digit number format. For example, press "000" for 0, "023" for 23, and "234" for 234.
-