



333 Bayview Avenue
Amityville, New York 11701
For Sales and Repairs, (800) 645-9445
For Technical Service, (800) 645-9440

© NAPCO 2004

GEM-RPB5 KEYPAD JUNCTION BOX MOUNTING KIT INSTALLATION INSTRUCTIONS

WI1302 7/04

The GEM-RPB5 Keypad junction box mounting kit allows NAPCO keypads to be installed into single or double-gang junction boxes. The GEM-RPB5 can be used with the following NAPCO keypads:

GEM-RP1CAe2	GEM-K1CA
GEM-RP2ASe2	GEM-K2AS
GEM-RP3DGTL	GEM-K3DGTL
GEM-RP4RFC	GEM-K4RF
GEM-RP4C	GEM-K4
CCRP1CA2	CC-K1CA
CCRP2AS2	CC-K2AS
CC-RP3DGTL	CC-K3DGTL
GEM-RP4	GEM-K400
GEM-RP8	GEM-K800
GEM-RP8LCD	

INSTALLATION:

1. Install the GEM-RPB5 into either a single or double-gang junction box using the screws provided with the junction box hardware. Use either two or four screws in the correct mounting holes, as shown below. **Note:** Other mounting holes are provided in the GEM-RPB5 to allow for the full range of existing junction boxes available.

WARNING: USE OF A DOUBLE-GANG JUNCTION BOX IS STRONGLY RECOMMENDED. BE AWARE THAT IF A SINGLE-GANG JUNCTION BOX IS USED, THE BOX **MUST NOT** BE INSTALLED TOO CLOSE TO THE ADJACENT DOOR FRAME, AS THE HOLES IN THE GEM-RPB5 USED FOR SINGLE-GANG MOUNTING ARE LOCATED TO THE FAR LEFT OF CENTER. ALWAYS MEASURE AND LOCATE THE GEM-RPB5 CAREFULLY BEFORE CUTTING INTO THE EXISTING WALLS OR MOUNTING SURFACES.

2. Route all keypad wires from the junction box through either the square or circular holes in the GEM-RPB5.
3. After the GEM-RPB5 is secured to the junction box, mount the rear of the keypad case to the GEM-RPB5 using the four SC254 screws provided. Be sure to route all wires through the keypad case before securing. **Note:** For single-gang mounting, the rear slide plate located at the rear of the keypad case can **not** be used.
4. Connect all keypad wires to the keypad as necessary.
5. Secure the keypad as usual by first inserting the 2 tabs at the bottom of the keypad and snapping the two tabs at the top of the keypad.

