

# Altronix® T2428100 Open Frame Transformer

### Specification Chart:


Model #	Input (Primary)	Output (Secondary)	<b>Agency Listing</b>
T2428100	115VAC, 50/60Hz, 1A	24VAC/100VA (4A) or 28VAC/100VA (3.5A)	<i>7</i> .1

#### Installation Instructions:


- 1. Mount transformer in the desired location/enclosure (refer to Transformer Drawing and Dimensions below).
- Connect AC power 115VAC, 50/60Hz to primary leads (black and white) (refer to Wiring Configuration below).
- 3. Measure output voltage across the secondary leads before connecting devices (refer to Wiring Configuration below). This helps avoiding potential damage.
  - Yellow and Brown for 24VAC (open circuit voltage @ 115VAC approx. 26.1VAC).
  - Black and Brown for 28VAC (open circuit voltage @ 115VAC approx. 30.4VAC).
- Connect 24VAC device(s) to Yellow and Brown leads or 28VAC device(s) to Black and Brown leads (refer to Wiring Configuration below).

WARNING: This installation should be made by qualified service personnel and should conform to the National Electrical Code and all local codes.

# Wiring Configuration:



## Transformer Drawing and Dimensions:



E26Q

